

NÚCLEO INTERCAMBIABLE INTERCHANGEABLE HUB

MOZZO INTERCAMBIABILE

MOYEU INTERCHANGEABLE

|   | 2T<br>STROKES | 4T<br>STROKES | A  |                   | REF        |   |
|---|---------------|---------------|----|-------------------|------------|---|
| 45-75 HP<br>Cola pequeña   Small gearcase<br>Piede piccolo   Embase courte<br>(1975+) |               |               |    | 3 <sup>3/8"</sup> | SOLRBX-111 | C |
| 45-75 HP<br>Cola larga   Large gearcase<br>Piede lungo   Embase Longue<br>(1968+)     |               |               | 13 |                   | SOLRBX-106 | D |
| 85-140 HP<br>Cola larga   Large gearcase<br>Piede lungo   Embase Longue<br>(1969+)    |               |               | 13 | 4 <sup>1/4"</sup> | SOLRBX-106 | D |
| 60 & 70 HP<br>(1998+)   |               | ✓             | 13 |                   | SOLRBX-110 | D |
| 90, 115 HP<br>(2003+)   |               | ✓             | 15 |                   | SOLRBX-125 | D |
| 140 HP<br>(2003+)   |               | ✓             | 15 |                   | SOLRBX-126 | D |
| 90, 140 HP<br>Cola larga   Large gearcase<br>Piede lungo   Embase Longue<br>(1976-90) |               |               | 15 |                   | SOLRBX-101 | E |
| 90, 140 HP<br>Cola larga   Large gearcase<br>Piede lungo   Embase Longue<br>(1991+)   |               |               | 15 |                   | SOLRBX-100 | E |
| 150-300 HP<br>(1976-90)   |               |               | 15 |                   | SOLRBX-101 | E |
| 150-300 HP<br>(1991+)   |               |               | 15 |                   | SOLRBX-100 | E |

RUBEX



HÉLICES PARA NÚCLEO INTERCAMBIABLE

PROPELLERS FOR INTERCHANGEABLE HUB

ELICHE PER MOZZO INTERCAMBIABILE

HELICES AVEC MOYEU INTERCHANGEABLE

|                        | B  | D     | P              | R | AL             |
|------------------------|----|-------|----------------|---|----------------|
| <b>C</b><br>30-75 HP   | 3  | 11.4  | 12             | R | SOL9311-114-12 |
|                        |    | 11.1  | 13             | R | SOL9311-111-13 |
|                        |    | 14    | 9              | R | SOL9411-140-09 |
| <b>D</b><br>40-140 HP  | 3  | 14    | 11             | R | SOL9411-140-11 |
|                        |    | 13.75 | 13             | R | SOL9411-138-13 |
|                        |    | 13.5  | 15             | R | SOL9411-135-15 |
|                        |    | 13.25 | 17             | R | SOL9411-133-17 |
|                        |    | 13.2  | 19             | R | SOL9411-132-19 |
|                        |    | 13.2  | 21             | R | SOL9411-132-21 |
| <b>E</b><br>135-350 HP | 3  | 15.5  | 11             | R | SOL9511-155-11 |
|                        |    | 16    | 13             | R | SOL9511-160-13 |
|                        |    | 15.3  | 13             | R | SOL9511-153-13 |
|                        |    | 15    | 15             | R | SOL9511-150-15 |
|                        |    | 15    | 15             | L | SOL9511-150-15 |
|                        |    | 14.8  | 17             | R | SOL9511-148-17 |
|                        |    | 14.8  | 17             | L | SOL9511-148-17 |
|                        |    | 14.5  | 19             | R | SOL9511-145-19 |
|                        |    | 14.5  | 19             | L | SOL9511-145-19 |
|                        |    | 14.3  | 21             | R | SOL9511-143-21 |
| 14.3                   | 21 | L     | SOL9511-143-21 |   |                |

|                        | B | D                 | P  | R | INOX<br>STAINLESS STEEL |
|------------------------|---|-------------------|----|---|-------------------------|
| <b>D</b><br>40-140 HP  | 3 | 13 <sup>3/4</sup> | 13 | R | SOL9431-138-13          |
|                        |   | 13 <sup>3/4</sup> | 13 | L | SOL9432-138-13          |
|                        |   | 13 <sup>1/2</sup> | 15 | R | SOL9431-135-15          |
|                        |   | 13 <sup>1/2</sup> | 15 | L | SOL9432-135-15          |
|                        |   | 13 <sup>1/4</sup> | 17 | R | SOL9431-133-17          |
|                        |   | 13 <sup>1/4</sup> | 17 | L | SOL9432-133-17          |
|                        |   | 13                | 19 | R | SOL9431-130-19          |
|                        |   | 13                | 19 | L | SOL9432-130-19          |
|                        |   | 13                | 21 | R | SOL9431-130-21          |
|                        |   | 13                | 21 | L | SOL9432-130-21          |
| <b>E</b><br>90-140 HP  | 3 | 14 <sup>1/2</sup> | 15 | R | SOL9531-145-15          |
|                        |   | 14 <sup>1/2</sup> | 15 | L | SOL9532-145-15          |
|                        |   | 14 <sup>1/4</sup> | 17 | R | SOL9531-143-17          |
|                        |   | 14 <sup>1/4</sup> | 17 | L | SOL9532-143-17          |
|                        |   | 14                | 19 | R | SOL9531-140-19          |
|                        |   | 14                | 19 | L | SOL9532-140-19          |
|                        |   | 14                | 21 | R | SOL9531-140-21          |
|                        |   | 14                | 21 | L | SOL9532-140-21          |
|                        |   | 14                | 23 | R | SOL9531-140-23          |
|                        |   | 14                | 23 | L | SOL9532-140-23          |
| <b>E</b><br>135-350 HP | 3 | 15 <sup>3/4</sup> | 15 | R | SOL9571-158-15          |
|                        |   | 15 <sup>3/4</sup> | 15 | L | SOL9572-158-15          |
|                        |   | 15 <sup>1/2</sup> | 17 | R | SOL9571-155-17          |
|                        |   | 15 <sup>1/2</sup> | 17 | L | SOL9572-155-17          |
|                        |   | 15 <sup>1/4</sup> | 19 | R | SOL9571-153-19          |
|                        |   | 15 <sup>1/4</sup> | 19 | L | SOL9572-153-19          |
|                        |   | 15                | 21 | R | SOL9571-150-21          |
|                        |   | 15                | 21 | L | SOL9572-150-21          |
|                        |   | 14 <sup>3/4</sup> | 23 | R | SOL9571-148-23          |
|                        |   | 14 <sup>3/4</sup> | 23 | L | SOL9572-148-23          |

RUBEX



Núcleo intercambiable (no incluido).  
Interchangeable hub (not included).  
Mozzo intercambiabile (non incluso).  
Moyeu interchangeable (non inclus)

